

REL-MGRDTH

Temporary Grounding Driver

NOTICE

Read and understand Instructions and all safety warnings before operation of this tool.

Failure to observe warnings may result in property damage and/or serious personal injury

DANGER

To avoid severe personal injury, inspect tool before each use.

WARNING

ELECTRICAL SHOCK HAZARD

Use EXTREME CAUTION when operating product near or around energized cables.

INSTRUCTIONS

INSTALLATION

Install and tighten thumb screw securing driver shaft.

Screw 5/8" threaded ground rod into threaded end of driver shaft.

Loosen thumb screw.

Grasp driver with both hands and impact rod down to desired depth.

Connect grounding cable from equipment that is to be grounded using a suitable connector/clamp.


REMOVAL

Remove cable from temporary ground assembly.

Impact driver upward to remove rod from the ground.

Tighten thumb screw.

Unscrew rod from driver and store.



HARD HAT



EYE PROTECTION



GLOVES
PROTECTIVE GARMENTS



HEARING PROTECTION



ELECTRICAL SHOCK
HAZARD



RELIABLE EQUIPMENT

CRAFTED WITH PRIDE IN THE U.S.A.
USED WITH CONFIDENCE AROUND THE WORLD

92 Steamwhistle Drive • Ivyland, PA 18974
Phone: 800-966-3530 • Fax: 215-357-9193
Visit us on the web at www.Reliable-Equip.com